

# **OsmoBTS VTY Reference**



**osmo-bts-virtual**

Copyright © 2023

This work is copyright by sysmocom - s.f.m.c. GmbH. All rights reserved.

---

**COLLABORATORS**

	<i>TITLE :</i> OsmoBTS VTY Reference		
<i>ACTION</i>	<i>NAME</i>	<i>DATE</i>	<i>SIGNATURE</i>
WRITTEN BY		March 21, 2023	

**REVISION HISTORY**

NUMBER	DATE	DESCRIPTION	NAME
v2	21th March 2023	Automatic build (1.5.0)	s.f.m.c.

# Contents

<b>1</b>	<b>VTY reference</b>	<b>1</b>
1.1	Common Commands	1
1.1.1	end	2
1.1.2	exit	2
1.1.3	help	2
1.1.4	list [with-flags]	2
1.1.5	show running-config	3
1.1.6	show vty-attributes	3
1.1.7	show vty-attributes (application library global)	3
1.1.8	write	4
1.1.9	write file [PATH]	4
1.1.10	write memory	4
1.1.11	write terminal	4
1.2	view	5
1.2.1	enable [expert-mode]	5
1.2.2	logging color (0 1)	5
1.2.3	logging disable	5
1.2.4	logging enable	6
1.2.5	logging filter all (0 1)	6
1.2.6	logging filter 11-sapi (unknown lagch bech cbch facch ffacch hlfch idle in ch pac...	6
1.2.7	logging level (rs l om lr l rr meas pag l cl l p ds p cu l ho l tr x l oo p lab is l rt p l glo...	8
1.2.8	logging level force-all (debug info notice error fatal)	11
1.2.9	logging level set-all (debug info notice error fatal)	11
1.2.10	logging print category (0 1)	12
1.2.11	logging print category-hex (0 1)	12
1.2.12	logging print extended-timestamp (0 1)	13
1.2.13	logging print file (0 1 basename) [last]	13
1.2.14	logging print level (0 1)	14
1.2.15	logging print thread-id (0 1)	14
1.2.16	logging set-log-mask MASK	15

1.2.17	logging timestamp (0 1)	15
1.2.18	logp (rsl lmlr lrrl meas pag l cl l plds plpcul holtrxl looplabis lrpl globall lapd...	16
1.2.19	no logging filter l1-sapi (unknown lagch bcch cbch facch/ffacch/hlfch idle lnchl...	18
1.2.20	no logging level force-all	20
1.2.21	show alarms	20
1.2.22	show asciidoc counters	21
1.2.23	show bts <0-255> gprs	21
1.2.24	show bts [<0-255>]	21
1.2.25	show cpu-sched threads	22
1.2.26	show e1_driver	22
1.2.27	show e1_line [<0-255>] [stats]	22
1.2.28	show e1_timeslot [<0-255>] [<0-31>]	23
1.2.29	show fsm NAME	23
1.2.30	show fsm all	23
1.2.31	show fsm-instances NAME	24
1.2.32	show fsm-instances all	24
1.2.33	show history	24
1.2.34	show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]	25
1.2.35	show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]	25
1.2.36	show logging vty	26
1.2.37	show online-help	26
1.2.38	show pid	26
1.2.39	show rate-counters [skip-zero]	27
1.2.40	show stats [skip-zero]	27
1.2.41	show stats level (global peer subscriber) [skip-zero]	27
1.2.42	show talloc-context (application global all) (full brief DEPTH)	28
1.2.43	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	28
1.2.44	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	29
1.2.45	show timer [(bts labis)] [TNNNN]	30
1.2.46	show timeslot [<0-255>] [<0-255>] [<0-7>]	30
1.2.47	show trx [<0-255>] [<0-255>]	31
1.2.48	show uptime	31
1.2.49	show version	31
1.2.50	terminal length <0-512>	32
1.2.51	terminal no length	32
1.2.52	who	32
1.3	enable	32
1.3.1	bts <0-0> c0-power-red <0-6>	33
1.3.2	bts <0-0> trx <0-255> ts <0-7> (lchan shadow-lchan) <0-7> rtp jitter-buffer <0-1...	33

1.3.3	configure terminal	34
1.3.4	copy running-config startup-config	34
1.3.5	disable	34
1.3.6	logging color (01)	35
1.3.7	logging disable	35
1.3.8	logging enable	35
1.3.9	logging filter all (01)	36
1.3.10	logging filter l1-sapi (unknownlagchlbchlfacch/flfacch/hlfchlidlelnchl...)	36
1.3.11	logging level (rsllomlrlrrlmeaspagll1cll1pldsplpculholtrxllooplabislrtpllglo...)	38
1.3.12	logging level force-all (debuglinfofnoticeerrorlfatal)	41
1.3.13	logging level set-all (debuglinfofnoticeerrorlfatal)	41
1.3.14	logging print category (01)	42
1.3.15	logging print category-hex (01)	42
1.3.16	logging print extended-timestamp (01)	43
1.3.17	logging print file (01 basename) [last]	43
1.3.18	logging print level (01)	44
1.3.19	logging print thread-id (01)	44
1.3.20	logging set-log-mask MASK	45
1.3.21	logging timestamp (01)	45
1.3.22	logp (rsllomlrlrrlmeaspagll1cll1pldsplpculholtrxllooplabislrtpllgloballllapd...)	45
1.3.23	no logging filter l1-sapi (unknownlagchlbchlfacch/flfacch/hlfchlidlelnchl...)	48
1.3.24	no logging level force-all	50
1.3.25	show alarms	50
1.3.26	show asciidoc counters	51
1.3.27	show bts <0-255> gprs	51
1.3.28	show bts [<0-255>]	51
1.3.29	show cpu-sched threads	52
1.3.30	show e1_driver	52
1.3.31	show e1_line [<0-255>] [stats]	52
1.3.32	show e1_timeslot [<0-255>] [<0-31>]	53
1.3.33	show fsm NAME	53
1.3.34	show fsm all	53
1.3.35	show fsm-instances NAME	54
1.3.36	show fsm-instances all	54
1.3.37	show history	54
1.3.38	show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]	55
1.3.39	show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]	55
1.3.40	show logging vty	56
1.3.41	show online-help	56

1.3.42	show rate-counters [skip-zero]	56
1.3.43	show startup-config	57
1.3.44	show stats [skip-zero]	57
1.3.45	show stats level (global peer subscriber) [skip-zero]	57
1.3.46	show talloc-context (application global all) (full brief DEPTH)	58
1.3.47	show talloc-context (application global all) (full brief DEPTH) filter REGEXP	58
1.3.48	show talloc-context (application global all) (full brief DEPTH) tree ADDRESS	59
1.3.49	show timer [(bts abis)] [TNNNN]	60
1.3.50	show timeslot [<0-255>] [<0-255>] [<0-7>]	60
1.3.51	show trx [<0-255>] [<0-255>]	61
1.3.52	show version	61
1.3.53	shutdown	61
1.3.54	stats report	62
1.3.55	stats reset	62
1.3.56	terminal length <0-512>	62
1.3.57	terminal monitor	63
1.3.58	terminal no length	63
1.3.59	terminal no monitor	63
1.3.60	test send-failure-event-report <0-255>	64
1.3.61	who	64
1.4	config	64
1.4.1	banner motd default	64
1.4.2	banner motd file [FILE]	65
1.4.3	bts BTS_NR	65
1.4.4	cpu-sched	65
1.4.5	ctrl	66
1.4.6	e1_input	66
1.4.7	enable password (8l) WORD	66
1.4.8	enable password LINE	67
1.4.9	hostname WORD	67
1.4.10	line vty	67
1.4.11	log alarms <2-32700>	68
1.4.12	log file FILENAME [blocking-io]	68
1.4.13	log gsmtap [HOSTNAME]	68
1.4.14	log stderr [blocking-io]	69
1.4.15	log syslog (auth priv cron daemon ftplib mail news user luucp)	69
1.4.16	log syslog local <0-7>	70
1.4.17	log systemd-journal [raw]	70
1.4.18	no banner motd	70

1.4.19	no enable password	71
1.4.20	no hostname [HOSTNAME]	71
1.4.21	no log alarms	71
1.4.22	no log file FILENAME	72
1.4.23	no log gsmmap [HOSTNAME]	72
1.4.24	no log stderr	72
1.4.25	no log syslog	73
1.4.26	no log systemd-journal	73
1.4.27	no service advanced-vty	73
1.4.28	no service terminal-length [<0-512>]	74
1.4.29	no stats reporter log [NAME]	74
1.4.30	no stats reporter statsd [NAME]	74
1.4.31	password (8) WORD	75
1.4.32	password LINE	75
1.4.33	phy <0-255>	76
1.4.34	service advanced-vty	76
1.4.35	service terminal-length <0-512>	76
1.4.36	show history	77
1.4.37	stats interval <0-65535>	77
1.4.38	stats reporter log [NAME]	77
1.4.39	stats reporter statsd [NAME]	78
1.4.40	stats-tcp batch-size <1-65535>	78
1.4.41	stats-tcp interval <0-65535>	78
1.4.42	timer [(btslabis)] [TNNNN] [(<0-2147483647> default)]	79
1.4.43	vtv telnet-port <0-65535>	79
1.5	config-log	79
1.5.1	logging color (01)	80
1.5.2	logging filter all (01)	80
1.5.3	logging level (rsllomlrllrrimeaspagllcllpldsplpculholtrxllooplabislrtpllglo...	81
1.5.4	logging level force-all (debug info notice error fatal)	83
1.5.5	logging level set-all (debug info notice error fatal)	84
1.5.6	logging print category (01)	85
1.5.7	logging print category-hex (01)	85
1.5.8	logging print extended-timestamp (01)	86
1.5.9	logging print file (01 basename) [last]	86
1.5.10	logging print level (01)	87
1.5.11	logging print thread-id (01)	87
1.5.12	logging timestamp (01)	88
1.5.13	no logging level force-all	88



1.6	config-stats	88
1.6.1	disable	88
1.6.2	enable	89
1.6.3	flush-period <0-65535>	89
1.6.4	level (globalpeersubscriber)	89
1.6.5	local-ip ADDR	90
1.6.6	mtu <100-65535>	90
1.6.7	no local-ip	90
1.6.8	no mtu	90
1.6.9	no prefix	91
1.6.10	prefix PREFIX	91
1.6.11	remote-ip ADDR	91
1.6.12	remote-port <1-65535>	91
1.7	config-line	92
1.7.1	bind A.B.C.D [<0-65535>]	92
1.7.2	login	92
1.7.3	no login	92
1.8	config-e1_input	93
1.8.1	e1_line <0-255> connect-timeout <0-60>	93
1.8.2	e1_line <0-255> driver (misdnmisdn_lapldahdle1dlipalunixsocket)	93
1.8.3	e1_line <0-255> ipa-keepalive <1-300> <1-300>	94
1.8.4	e1_line <0-255> keepalive	94
1.8.5	e1_line <0-255> keepalive <1-300> <1-20> <1-300>	95
1.8.6	e1_line <0-255> name .LINE	95
1.8.7	e1_line <0-255> pcap .FILE	96
1.8.8	e1_line <0-255> port <0-255>	96
1.8.9	e1_line <0-255> socket .SOCKET	97
1.8.10	ipa bind A.B.C.D	97
1.8.11	ipa ip-dscp (omllrsl) <0-63>	98
1.8.12	ipa socket-priority (omllrsl) <0-255>	98
1.8.13	no e1_line <0-255> ipa-keepalive	99
1.8.14	no e1_line <0-255> keepalive	99
1.8.15	no e1_line <0-255> pcap	100
1.9	config-ctrl	100
1.9.1	bind A.B.C.D [<0-65535>]	100
1.10	config-cpu-sched	101
1.10.1	cpu-affinity (selflall<0-4294967295> THREADNAME) CPUHEXMASK [delay]	101
1.10.2	policy rr <1-32>	101
1.11	phy	102

1.11.1	instance <0-255>	102
1.11.2	no instance <0-255>	102
1.11.3	virtual-um bts-multicast-group GROUP	102
1.11.4	virtual-um bts-udp-port <0-65535>	103
1.11.5	virtual-um ms-multicast-group GROUP	103
1.11.6	virtual-um ms-udp-port <0-65535>	103
1.11.7	virtual-um net-device NETDEV	104
1.11.8	virtual-um ttl <0-255>	104
1.12	phy-inst	104
1.12.1	osmotrx maxdly <0-63>	104
1.12.2	osmotrx maxdlynb <0-63>	105
1.13	bts	105
1.13.1	agch-queue-mgmt default	105
1.13.2	agch-queue-mgmt threshold <0-100> low <0-100> high <0-100000>	105
1.13.3	band (450 GSM450 480 GSM480 750 GSM750 810 GSM810 850 GSM850 900 GSM900 1800 DCS...	106
1.13.4	description .TEXT	107
1.13.5	gsmtap-remote-host [HOSTNAME]	107
1.13.6	gsmtap-sapi (bcch ccch rach lagch pchs dcch tch/fltch/hlpacch pdtch ptcch cbch sa...	108
1.13.7	gsmtap-sapi (enable-all disable-all)	109
1.13.8	ipa unit-id <0-65534> <0-255>	109
1.13.9	max-ber10k-rach <0-10000>	109
1.13.10	min-qual-norm <-100-100>	110
1.13.11	min-qual-rach <-100-100>	110
1.13.12	no description	110
1.13.13	no gsmtap-remote-host	111
1.13.14	no gsmtap-sapi (bcch ccch rach lagch pchs dcch tch/fltch/hlpacch pdtch ptcch cbch...	111
1.13.15	no oml remote-ip A.B.C.D	112
1.13.16	no supp-meas-info toa256	112
1.13.17	oml remote-ip A.B.C.D	113
1.13.18	paging lifetime <0-60>	113
1.13.19	paging queue-size <1-1024>	113
1.13.20	pcu-socket PATH	114
1.13.21	rtp ip-dscp <0-63>	114
1.13.22	rtp jitter-buffer <0-10000> [adaptive]	115
1.13.23	rtp port-range <1-65534> <1-65534>	115
1.13.24	rtp socket-priority <0-255>	116
1.13.25	smscb queue-hysteresis <0-30>	116
1.13.26	smscb queue-max-length <1-60>	117
1.13.27	smscb queue-target-length <1-30>	117

---

1.13.28	supp-meas-info toa256	118
1.13.29	trx <0-254>	118
1.14	trx	118
1.14.1	ms-power-control (dsplosmo)	118
1.14.2	phy <0-255> instance <0-255>	119
1.14.3	power-ramp max-initial <-10000-100000> (dBm mdBm)	119
1.14.4	power-ramp step-interval <1-100>	119
1.14.5	power-ramp step-size <1-100000> (dB mdB)	120
1.14.6	ta-control interval <0-31>	120
1.14.7	user-gain <-100000-100000> (dB mdB)	121

---

# List of Tables

1.1	VTY Parameter Patterns . . . . .	1
1.2	VTY port numbers . . . . .	1

# Chapter 1

## VTY reference

The Virtual Tele Type (VTY) has the concept of nodes and commands. This chapter lists all nodes and the commands that are available within the node. Each command can consist out of several words followed by a variable number of parameters. There are common patterns for the parameters, these include IPv4 addresses, number ranges, a word, a line of text and choice. The following will explain the commonly used patterns.

Pattern	Example	Explanation
A.B.C.D	127.0.0.1	A IPv4 address
TEXT	example01	A single string without any spaces, tabs
.TEXT	Some information	A line of text
(OptionA OptionB OptionC)	OptionA	A choice between a list of available options
<0-10>	5	A number from a range

Table 1.1: VTY Parameter Patterns

The application is configured through the VTY. For configuring a system one needs to enter the **enable** node and then enter the **configure terminal** command. Then the configuration can be made according to the available commands. After the system has been configured one can use the **write** command to write the new configuration to the configuration file. The new file will be used after the application has been restarted.

The following table lists the TCP port numbers of the VTY for the various Osmocom GSM related programs as used on sismocom products:

Port Number	Software
4240	osmo-pcu
4241	osmo-bts
4242	osmo-nitb, osmo-bsc
4243	osmo-bsc_mgcp
4244	osmo-bsc_nat
4245	osmo-sgsn
4246	osmo-gbproxy

Table 1.2: VTY port numbers

### 1.1 Common Commands

These commands are available on all VTY nodes. They are listed here only once, to unclutter the VTY reference.

### 1.1.1 end

#### Command

```
end
```

#### Parameters

end

End current mode and change to enable mode.

### 1.1.2 exit

#### Command

```
exit
```

#### Parameters

exit

Exit current mode and down to previous mode

### 1.1.3 help

#### Command

```
help
```

#### Parameters

help

Description of the interactive help system

### 1.1.4 list [with-flags]

#### Command

```
list [with-flags]
```

#### Parameters

list

Print command list

[with-flags]

Also print the VTY attribute flags

---

### 1.1.5 show running-config

#### Command

```
show running-config
```

#### Parameters

show

Show running system information

running-config

running configuration

### 1.1.6 show vty-attributes

#### Command

```
show vty-attributes
```

#### Parameters

show

Show running system information

vtty-attributes

List of VTY attributes

### 1.1.7 show vty-attributes (application|library|global)

#### Command

```
show vty-attributes (application|library|global)
```

#### Parameters

show

Show running system information

vtty-attributes

List of VTY attributes

application

Application specific attributes only

library

Library specific attributes only

global

Global attributes only

---

### 1.1.8 write

Command

```
write
```

Parameters

write

Write running configuration to memory, network, or terminal

### 1.1.9 write file [PATH]

Command

```
write file [PATH]
```

Parameters

write

Write running configuration to memory, network, or terminal

file

Write to configuration file

[PATH]

Set file path to store the config, or replace if already exists

### 1.1.10 write memory

Command

```
write memory
```

Parameters

write

Write running configuration to memory, network, or terminal

memory

Write configuration to the file (same as write file)

### 1.1.11 write terminal

Command

```
write terminal
```

Parameters

write

Write running configuration to memory, network, or terminal

terminal

Write to terminal



## 1.2 view

The view node is the default node when connecting to the VTY interface. This node does not require any additional permission and allows to introspect the application.

### 1.2.1 enable [expert-mode]

#### Command

```
enable [expert-mode]
```

#### Parameters

enable

Turn on privileged mode command

[expert-mode]

Enable the expert mode (show hidden commands)

### 1.2.2 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

logging

Configure logging

color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.2.3 logging disable

#### Command

```
logging disable
```

#### Parameters

logging

Configure logging

disable

Disables logging to this vty

### 1.2.4 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

logging

Configure logging

enable

Enables logging to this vty

### 1.2.5 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

logging

Configure logging

filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.2.6 logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pac...

#### Command

```
logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pacch| ←  
pagch|pbcch|pch|pdtch|pnch|ppch|prach|ptcch|rach|sacch|sch|sdcch|tch/f|tch/h)
```

## Parameters

## logging

- Configure logging

## filter

- Filter log messages

## l1-sapi

- L1 SAPI

## unknown

- UNKNOWN

## agch

- AGCH

## bcch

- BCCH

## cbch

- CBCH

## facch/f

- FACCH/F

## facch/h

- FACCH/H

## fcch

- FCCH

## idle

- IDLE

## nch

- NCH

## pacch

- PACCH

## pagch

- PAGCH

## pbccch

- PBCCCH

## pch

- PCH

## pdtch

- PDTCH

## pnch

- PNCH

## ppch

- PPCH

prach

PRACH

ptcch

PTCCH

rach

RACH

sacch

SACCH

sch

SCH

sdccch

SDCCH

tch/f

TCH/F

tch/h

TCH/H

### 1.2.7 logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal|

Command

```
logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal| ↔
llapd|linp|lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua| ↔
lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1) (debug|info| ↔
notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

rsl

A-bis Radio Siganlling Link (RSL)

oml

A-bis Network Management / O&M (NM/OML)

rll

A-bis Radio Link Layer (RLL)

rr

Layer3 Radio Resource (RR)

meas

Radio Measurement Processing

---

pag  
Paging Subsystem

llc  
Layer 1 Control (MPH)

llp  
Layer 1 Primitives (PH)

dsp  
DSP Trace Messages

pcu  
PCU interface

ho  
Handover

trx  
TRX interface

loop  
Control loops

abis  
A-bis Input Subsystem

rtp  
Realtime Transfer Protocol

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

---

---

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lscpp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lnsdata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

---

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.8 logging level force-all (debug|info|notice|error|fatal)

Command

```
logging level force-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

debug

Log debug messages and higher levels

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.2.9 logging level set-all (debug|info|notice|error|fatal)

Command

```
logging level set-all (debug|info|notice|error|fatal)
```

Parameters

logging

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.2.10 logging print category (0|1)

**Command**

```
logging print category (0|1)
```

**Parameters****logging**

Configure logging

**print**

Log output settings

**category**

Configure log message

**0**

Don't prefix each log message

**1**

Prefix each log message with category/subsystem name

### 1.2.11 logging print category-hex (0|1)

**Command**

```
logging print category-hex (0|1)
```

**Parameters**



## logging

Configure logging

## print

Log output settings

## category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.2.12 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

## logging

Configure logging

## print

Log output settings

## extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.2.13 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

## logging

Configure logging

## print

Log output settings

file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

basename

Prefix each log message with the source file's basename (strip leading paths) and line

[last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.2.14 logging print level (0|1)

Command

```
logging print level (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.2.15 logging print thread-id (0|1)

Command

```
logging print thread-id (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

### 1.2.16 logging set-log-mask MASK

Command

```
logging set-log-mask MASK
```

Parameters

logging

Configure logging

set-log-mask

Set the logmask of this logging target

MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.2.17 logging timestamp (0|1)

Command

```
logging timestamp (0|1)
```

Parameters

logging

Configure logging

timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

## 1.2.18 logp (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal|llapd...

### Command

```
logp (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal|llapd|linp| ↵
      lmux|lmi|lmib|lsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf| ↵
      lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1) (debug|info|notice|error| ↵
      fatal) .LOGMESSAGE
```

### Parameters

#### logp

Print a message on all log outputs; useful for placing markers in test logs

#### rsl

A-bis Radio Siganlling Link (RSL)

#### oml

A-bis Network Management / O&M (NM/OML)

#### rll

A-bis Radio Link Layer (RLL)

#### rr

Layer3 Radio Resource (RR)

#### meas

Radio Measurement Processing

#### pag

Paging Subsystem

#### l1c

Layer 1 Control (MPH)

#### l1p

Layer 1 Primitives (PH)

#### dsp

DSP Trace Messages

#### pcu

PCU interface

#### ho

Handover

#### trx

TRX interface

#### loop

Control loops

#### abis

A-bis Input Subsystem

---

rtp  
Realtime Transfer Protocol

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

---

lrspro  
Remote SIM protocol

lrs  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lrsdata  
GPRS NS layer data PDU

lrsignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

.LOGMESSAGE  
Arbitrary message to log on given category and log level

### 1.2.19 no logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|...

#### Command

```
no logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pacch| ←  
pagch|pbccch|pch|pdtch|pnch|ppch|prach|ptcch|rach|sacch|sch|sdcch|tch/f|tch/h)
```

#### Parameters

no  
Negate a command or set its defaults

logging

Configure logging

filter

Filter log messages

l1-sapi

L1 SAPI

unknown

UNKNOWN

agch

AGCH

bcch

BCCH

cbch

CBCH

facch/f

FACCH/F

facch/h

FACCH/H

fcch

FCCH

idle

IDLE

nch

NCH

pacch

PACCH

pagch

PAGCH

pbccch

PBCCH

pch

PCH

pdtech

PDTCH

pnch

PNCH

ppch

PPCH

---

prach  
    PRACH

ptcch  
    PTCCH

rach  
    RACH

sacch  
    SACCH

sch  
    SCH

sdcch  
    SDCCH

tch/f  
    TCH/F

tch/h  
    TCH/H

### 1.2.20 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.2.21 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration



### 1.2.22 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.2.23 show bts <0-255> gprs

#### Command

```
show bts <0-255> gprs
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

<0-255>

BTS Number

gprs

GPRS/EGPRS configuration

### 1.2.24 show bts [<0-255>]

#### Command

```
show bts [<0-255>]
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

[<0-255>]

BTS Number

### 1.2.25 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.2.26 show e1\_driver

#### Command

```
show e1_driver
```

#### Parameters

show

Show running system information

e1\_driver

Display information about available E1 drivers

### 1.2.27 show e1\_line [<0-255>] [stats]

#### Command

```
show e1_line [<0-255>] [stats]
```

#### Parameters

show

Show running system information

e1\_line

Display information about a E1 line

[<0-255>]

E1 Line Number

[stats]

Include statistics

---

### 1.2.28 show e1\_timeslot [<0-255>] [<0-31>]

#### Command

```
show e1_timeslot [<0-255>] [<0-31>]
```

#### Parameters

show

Show running system information

e1\_timeslot

Display information about a E1 timeslot

[<0-255>]

E1 Line Number

[<0-31>]

E1 Timeslot Number

### 1.2.29 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

NAME

Display information about a single named finite state machine

### 1.2.30 show fsm all

#### Command

```
show fsm all
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

all

Display a list of all registered finite state machines

### 1.2.31 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

NAME

Display a list of all FSM instances of the named finite state machine

### 1.2.32 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

### 1.2.33 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.2.34 show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]

#### Command

```
show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[<0-7>]

Logical Channel Number

### 1.2.35 show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]

#### Command

```
show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

summary

Short summary

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[<0-7>]

Logical Channel Number

### 1.2.36 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.2.37 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.2.38 show pid

#### Command

```
show pid
```

#### Parameters

##### show

Show running system information

##### pid

Displays the process ID

### 1.2.39 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

show

Show running system information

rate-counters

Show all rate counters

[skip-zero]

Skip items with total count zero

### 1.2.40 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

[skip-zero]

Skip items with total count zero

### 1.2.41 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

show

Show running system information

stats

Show statistical values

level

Set the maximum group level

---

global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

[skip-zero]

Skip items with total count zero

### 1.2.42 show talloc-context (application|global|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.2.43 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

---



show  
    Show running system information

talloc-context  
    Show talloc memory hierarchy

application  
    Application's context

global  
    Global context (OTC\_GLOBAL)

all  
    All contexts, if NULL-context tracking is enabled

full  
    Display a full talloc memory hierarchy

brief  
    Display a brief talloc memory hierarchy

DEPTH  
    Specify required maximal depth value

filter  
    Filter chunks using regular expression

REGEXP  
    Regular expression

#### 1.2.44 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

##### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

##### Parameters

show  
    Show running system information

talloc-context  
    Show talloc memory hierarchy

application  
    Application's context

global  
    Global context (OTC\_GLOBAL)

all  
    All contexts, if NULL-context tracking is enabled

full  
    Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

tree

Display only a specific memory chunk

ADDRESS

Chunk address (e.g. 0xdeadbeef)

### 1.2.45 show timer [(bts|abis)] [TNNNN]

Command

```
show timer [(bts|abis)] [TNNNN]
```

Parameters

show

Show running system information

timer

Show timers

[bts]

BTS process timers

[abis]

Abis (RSL) related timers

[TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

### 1.2.46 show timeslot [<0-255>] [<0-255>] [<0-7>]

Command

```
show timeslot [<0-255>] [<0-255>] [<0-7>]
```

Parameters

show

Show running system information

timeslot

Display information about a TS

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

### 1.2.47 show trx [<0-255>] [<0-255>]

#### Command

```
show trx [<0-255>] [<0-255>]
```

#### Parameters

show

Show running system information

trx

Display information about a TRX

[<0-255>]

BTS Number

[<0-255>]

TRX Number

### 1.2.48 show uptime

#### Command

```
show uptime
```

#### Parameters

show

Show running system information

uptime

Displays how long the program has been running

### 1.2.49 show version

#### Command

```
show version
```

#### Parameters

show

Show running system information

version

Displays program version

### 1.2.50 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

##### terminal

Set terminal line parameters

##### length

Set number of lines on a screen

##### <0-512>

Number of lines on screen (0 for no pausing)

### 1.2.51 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.2.52 who

#### Command

```
who
```

#### Parameters

##### who

Display who is on vty

## 1.3 enable

The enable node is a privileged node, allowing to make changes to the configuration and to access further commands like 'configure'. All commands seen on the view node are also available here.

---

### 1.3.1 **bts <0-0> c0-power-red <0-6>**

#### Command

```
bts <0-0> c0-power-red <0-6>
```

#### Parameters

bts

BTS Specific Commands

<0-0>

BTS Number

c0-power-red

BCCH carrier power reduction operation

<0-6>

Power reduction value (in dB, even numbers only)

### 1.3.2 **bts <0-0> trx <0-255> ts <0-7> (lchan|shadow-lchan) <0-7> rtp jitter-buffer <0-1...**

#### Command

```
bts <0-0> trx <0-255> ts <0-7> (lchan|shadow-lchan) <0-7> rtp jitter-buffer <0-10000>
```

#### Parameters

bts

BTS related commands

<0-0>

BTS number

trx

TRX related commands

<0-255>

TRX number

ts

timeslot related commands

<0-7>

timeslot number

lchan

Primary logical channel commands

shadow-lchan

Shadow logical channel commands

<0-7>

logical channel number

rtp

RTP settings

jitter-buffer

Jitter buffer

<0-10000>

Size of jitter buffer in (ms)

### 1.3.3 configure terminal

Command

```
configure terminal
```

Parameters

configure

Configuration from vty interface

terminal

Configuration terminal

### 1.3.4 copy running-config startup-config

Command

```
copy running-config startup-config
```

Parameters

copy

Copy configuration

running-config

Copy running config to...

startup-config

Copy running config to startup config (same as write file)

### 1.3.5 disable

Command

```
disable
```

Parameters

disable

Turn off privileged mode command

### 1.3.6 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.3.7 logging disable

#### Command

```
logging disable
```

#### Parameters

##### logging

Configure logging

##### disable

Disables logging to this vty

### 1.3.8 logging enable

This command is required to make logging commands available on the telnet VTY.

#### Command

```
logging enable
```

#### Parameters

##### logging

Configure logging

##### enable

Enables logging to this vty

### 1.3.9 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### all

Do you want to log all messages?

##### 0

Only print messages matched by other filters

##### 1

Bypass filter and print all messages

### 1.3.10 logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pac...

#### Command

```
logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pacch| ←
pagch|pbccch|pch|pdtch|pnch|ppch|prach|ptcch|rach|sacch|sch|sdcch|tch/f|tch/h)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

##### l1-sapi

L1 SAPI

##### unknown

UNKNOWN

##### agch

AGCH



---

bcch  
    BCCH

cbch  
    CBCH

facch/f  
    FACCH/F

facch/h  
    FACCH/H

fcch  
    FCCH

idle  
    IDLE

nch  
    NCH

pacch  
    PACCH

pagch  
    PAGCH

pbccch  
    PBCCH

pch  
    PCH

pdтч  
    PDTCH

pnch  
    PNCH

ppch  
    PPCH

prach  
    PRACH

ptcch  
    PTCCH

rach  
    RACH

sacch  
    SACCH

sch  
    SCH

---

sdch

SDCCH

tch/f

TCH/F

tch/h

TCH/H

### 1.3.11 logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglo...

Command

```
logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal| ←
llapd|linp|lmux|lmi|lmib|lmsms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua| ←
lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1) (debug|info| ←
notice|error|fatal)
```

Parameters

logging

Configure logging

level

Set the log level for a specified category

rsl

A-bis Radio Signalling Link (RSL)

oml

A-bis Network Management / O&M (NM/OML)

rll

A-bis Radio Link Layer (RLL)

rr

Layer3 Radio Resource (RR)

meas

Radio Measurement Processing

pag

Paging Subsystem

l1c

Layer 1 Control (MPH)

l1p

Layer 1 Primitives (PH)

dsp

DSP Trace Messages

pcu

PCU interface

---

ho  
Handover

trx  
TRX interface

loop  
Control loops

abis  
A-bis Input Subsystem

rtp  
Realtime Transfer Protocol

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lntp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lscpp  
libosmo-sigtran SCCP Implementation

---

---

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lndata  
GPRS NS layer data PDU

lnsignal  
GPRS NS layer signal PDU

liuup  
Iu UP layer

lpfcp  
libosmo-pfcp Packet Forwarding Control Protocol

lcsn1  
libosmo-csn1 Concrete Syntax Notation 1 codec

debug  
Log debug messages and higher levels

info  
Log informational messages and higher levels

notice  
Log noticeable messages and higher levels

error  
Log error messages and higher levels

fatal  
Log only fatal messages

---

### 1.3.12 logging level force-all (debug|info|notice|error|fatal)

#### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### force-all

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

##### debug

Log debug messages and higher levels

##### info

Log informational messages and higher levels

##### notice

Log noticeable messages and higher levels

##### error

Log error messages and higher levels

##### fatal

Log only fatal messages

### 1.3.13 logging level set-all (debug|info|notice|error|fatal)

#### Command

```
logging level set-all (debug|info|notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### set-all

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

##### debug

Log debug messages and higher levels

---

info

Log informational messages and higher levels

notice

Log noticeable messages and higher levels

error

Log error messages and higher levels

fatal

Log only fatal messages

### 1.3.14 logging print category (0|1)

Command

```
logging print category (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.3.15 logging print category-hex (0|1)

Command

```
logging print category-hex (0|1)
```

Parameters

logging

Configure logging

print

Log output settings

category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.3.16 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.3.17 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.3.18 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.3.19 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID



### 1.3.20 logging set-log-mask MASK

#### Command

```
logging set-log-mask MASK
```

#### Parameters

##### logging

Configure logging

##### set-log-mask

Set the logmask of this logging target

##### MASK

List of logging categories to log, e.g. 'abc:mno:xyz'. Available log categories depend on the specific application, refer to the 'logging level' command. Optionally add individual log levels like 'abc,1:mno,3:xyz,5', where the level numbers are LOGL\_DEBUG=1 LOGL\_INFO=3 LOGL\_NOTICE=5 LOGL\_ERROR=7 LOGL\_FATAL=8

### 1.3.21 logging timestamp (0|1)

#### Command

```
logging timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

### 1.3.22 logp (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal|llapd...

#### Command

```
logp (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal|llapd|linp| ↵
    lmx|lmi|lmib|lms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua|lmgcp|ljibuf| ↵
    lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1) (debug|info|notice|error| ↵
    fatal) .LOGMESSAGE
```

#### Parameters

---

logp  
Print a message on all log outputs; useful for placing markers in test logs

rsl  
A-bis Radio Siganlling Link (RSL)

oml  
A-bis Network Management / O&M (NM/OML)

rll  
A-bis Radio Link Layer (RLL)

rr  
Layer3 Radio Resource (RR)

meas  
Radio Measurement Processing

pag  
Paging Subsystem

llc  
Layer 1 Control (MPH)

llp  
Layer 1 Primitives (PH)

dsp  
DSP Trace Messages

pcu  
PCU interface

ho  
Handover

trx  
TRX interface

loop  
Control loops

abis  
A-bis Input Subsystem

rtp  
Realtime Transfer Protocol

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

---

---

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

ljibuf  
libosmo-netif Jitter Buffer

lrspro  
Remote SIM protocol

lns  
GPRS NS layer

lbssgp  
GPRS BSSGP layer

lndata  
GPRS NS layer data PDU

---

**Inssignal**  
 GPRS NS layer signal PDU

**liuup**  
 Iu UP layer

**lpfcp**  
 libosmo-pfcp Packet Forwarding Control Protocol

**lcsn1**  
 libosmo-csn1 Concrete Syntax Notation 1 codec

**debug**  
 Log debug messages and higher levels

**info**  
 Log informational messages and higher levels

**notice**  
 Log noticeable messages and higher levels

**error**  
 Log error messages and higher levels

**fatal**  
 Log only fatal messages

**.LOGMESSAGE**  
 Arbitrary message to log on given category and log level

### 1.3.23 no logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|...

Command

```
no logging filter l1-sapi (unknown|agch|bcch|cbch|facch/f|facch/h|fcch|idle|nch|pacch| ←
pagch|pbccch|pch|pdtch|pnch|ppch|prach|ptcch|rach|sacch|sch|sdcch|tch/f|tch/h)
```

Parameters

**no**  
 Negate a command or set its defaults

**logging**  
 Configure logging

**filter**  
 Filter log messages

**l1-sapi**  
 L1 SAPI

**unknown**  
 UNKNOWN

agch

AGCH

bcch

BCCH

cbch

CBCH

facch/f

FACCH/F

facch/h

FACCH/H

fcch

FCCH

idle

IDLE

nch

NCH

pacch

PACCH

pagch

PAGCH

pbccch

PBCCH

pch

PCH

pdтч

PDTCH

pnch

PNCH

ppch

PPCH

prach

PRACH

ptcch

PTCCH

rach

RACH

sacch

SACCH

sch

SCH

sdccch

SDCCCH

tch/f

TCH/F

tch/h

TCH/H

### 1.3.24 no logging level force-all

Command

```
no logging level force-all
```

Parameters

no

Negate a command or set its defaults

logging

Configure logging

level

Set the log level for a specified category

force-all

Release any globally forced log level set with 'logging level force-all <level>'

### 1.3.25 show alarms

Command

```
show alarms
```

Parameters

show

Show running system information

alarms

Show current logging configuration

### 1.3.26 show asciidoc counters

#### Command

```
show asciidoc counters
```

#### Parameters

show

Show running system information

asciidoc

Asciidoc generation

counters

Generate table of all registered counters

### 1.3.27 show bts <0-255> gprs

#### Command

```
show bts <0-255> gprs
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

<0-255>

BTS Number

gprs

GPRS/EGPRS configuration

### 1.3.28 show bts [<0-255>]

#### Command

```
show bts [<0-255>]
```

#### Parameters

show

Show running system information

bts

Display information about a BTS

[<0-255>]

BTS Number

### 1.3.29 show cpu-sched threads

#### Command

```
show cpu-sched threads
```

#### Parameters

show

Show running system information

cpu-sched

Show Sched section information

threads

Show information about running threads)

### 1.3.30 show e1\_driver

#### Command

```
show e1_driver
```

#### Parameters

show

Show running system information

e1\_driver

Display information about available E1 drivers

### 1.3.31 show e1\_line [<0-255>] [stats]

#### Command

```
show e1_line [<0-255>] [stats]
```

#### Parameters

show

Show running system information

e1\_line

Display information about a E1 line

[<0-255>]

E1 Line Number

[stats]

Include statistics

---



### 1.3.32 show e1\_timeslot [<0-255>] [<0-31>]

#### Command

```
show e1_timeslot [<0-255>] [<0-31>]
```

#### Parameters

show

Show running system information

e1\_timeslot

Display information about a E1 timeslot

[<0-255>]

E1 Line Number

[<0-31>]

E1 Timeslot Number

### 1.3.33 show fsm NAME

#### Command

```
show fsm NAME
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

NAME

Display information about a single named finite state machine

### 1.3.34 show fsm all

#### Command

```
show fsm all
```

#### Parameters

show

Show running system information

fsm

Show information about finite state machines

all

Display a list of all registered finite state machines

---

### 1.3.35 show fsm-instances NAME

#### Command

```
show fsm-instances NAME
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

NAME

Display a list of all FSM instances of the named finite state machine

### 1.3.36 show fsm-instances all

#### Command

```
show fsm-instances all
```

#### Parameters

show

Show running system information

fsm-instances

Show information about finite state machine instances

all

Display a list of all FSM instances of all finite state machine

### 1.3.37 show history

#### Command

```
show history
```

#### Parameters

show

Show running system information

history

Display the session command history

### 1.3.38 show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]

#### Command

```
show lchan [<0-255>] [<0-255>] [<0-7>] [<0-7>]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[<0-7>]

Logical Channel Number

### 1.3.39 show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]

#### Command

```
show lchan summary [<0-255>] [<0-255>] [<0-7>] [<0-7>]
```

#### Parameters

show

Show running system information

lchan

Display information about a logical channel

summary

Short summary

[<0-255>]

BTS Number

[<0-255>]

TRX Number

[<0-7>]

Timeslot Number

[<0-7>]

Logical Channel Number

### 1.3.40 show logging vty

#### Command

```
show logging vty
```

#### Parameters

##### show

Show running system information

##### logging

Show current logging configuration

##### vtty

Show current logging configuration for this vty

### 1.3.41 show online-help

#### Command

```
show online-help
```

#### Parameters

##### show

Show running system information

##### online-help

Online help

### 1.3.42 show rate-counters [skip-zero]

#### Command

```
show rate-counters [skip-zero]
```

#### Parameters

##### show

Show running system information

##### rate-counters

Show all rate counters

##### [skip-zero]

Skip items with total count zero

### 1.3.43 show startup-config

#### Command

```
show startup-config
```

#### Parameters

##### show

Show running system information

##### startup-config

Contentes of startup configuration

### 1.3.44 show stats [skip-zero]

#### Command

```
show stats [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### [skip-zero]

Skip items with total count zero

### 1.3.45 show stats level (global|peer|subscriber) [skip-zero]

#### Command

```
show stats level (global|peer|subscriber) [skip-zero]
```

#### Parameters

##### show

Show running system information

##### stats

Show statistical values

##### level

Set the maximum group level

##### global

Show global groups only

peer

Show global and network peer related groups

subscriber

Show global, peer, and subscriber groups

[skip-zero]

Skip items with total count zero

### 1.3.46 show talloc-context (application|global|all) (full|brief|DEPTH)

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH)
```

Parameters

show

Show running system information

talloc-context

Show talloc memory hierarchy

application

Application's context

global

Global context (OTC\_GLOBAL)

all

All contexts, if NULL-context tracking is enabled

full

Display a full talloc memory hierarchy

brief

Display a brief talloc memory hierarchy

DEPTH

Specify required maximal depth value

### 1.3.47 show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP

Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) filter REGEXP
```

Parameters

show

Show running system information

talloc-context  
    Show talloc memory hierarchy

application  
    Application's context

global  
    Global context (OTC\_GLOBAL)

all  
    All contexts, if NULL-context tracking is enabled

full  
    Display a full talloc memory hierarchy

brief  
    Display a brief talloc memory hierarchy

DEPTH  
    Specify required maximal depth value

filter  
    Filter chunks using regular expression

REGEXP  
    Regular expression

### 1.3.48 show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS

#### Command

```
show talloc-context (application|global|all) (full|brief|DEPTH) tree ADDRESS
```

#### Parameters

show  
    Show running system information

talloc-context  
    Show talloc memory hierarchy

application  
    Application's context

global  
    Global context (OTC\_GLOBAL)

all  
    All contexts, if NULL-context tracking is enabled

full  
    Display a full talloc memory hierarchy

brief  
    Display a brief talloc memory hierarchy

**DEPTH**

Specify required maximal depth value

**tree**

Display only a specific memory chunk

**ADDRESS**

Chunk address (e.g. 0xdeadbeef)

**1.3.49 show timer [(bts|abis)] [TNNNN]****Command**

```
show timer [(bts|abis)] [TNNNN]
```

**Parameters****show**

Show running system information

**timer**

Show timers

**[bts]**

BTS process timers

**[abis]**

Abis (RSL) related timers

**[TNNNN]**

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

**1.3.50 show timeslot [<0-255>] [<0-255>] [<0-7>]****Command**

```
show timeslot [<0-255>] [<0-255>] [<0-7>]
```

**Parameters****show**

Show running system information

**timeslot**

Display information about a TS

**[<0-255>]**

BTS Number

**[<0-255>]**

TRX Number

**[<0-7>]**

Timeslot Number



### 1.3.51 show trx [<0-255>] [<0-255>]

#### Command

```
show trx [<0-255>] [<0-255>]
```

#### Parameters

show

Show running system information

trx

Display information about a TRX

[<0-255>]

BTS Number

[<0-255>]

TRX Number

### 1.3.52 show version

#### Command

```
show version
```

#### Parameters

show

Show running system information

version

Displays program version

### 1.3.53 shutdown

#### Command

```
shutdown
```

#### Parameters

shutdown

Request a shutdown of the program

### 1.3.54 stats report

#### Command

```
stats report
```

#### Parameters

stats

Stats related commands

report

Manurally trigger reporting of stats

### 1.3.55 stats reset

#### Command

```
stats reset
```

#### Parameters

stats

Stats related commands

reset

Reset all rate counter stats

### 1.3.56 terminal length <0-512>

#### Command

```
terminal length <0-512>
```

#### Parameters

terminal

Set terminal line parameters

length

Set number of lines on a screen

<0-512>

Number of lines on screen (0 for no pausing)

---

### 1.3.57 terminal monitor

#### Command

```
terminal monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### monitor

Copy debug output to the current terminal line

### 1.3.58 terminal no length

#### Command

```
terminal no length
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### length

Set number of lines on a screen

### 1.3.59 terminal no monitor

#### Command

```
terminal no monitor
```

#### Parameters

##### terminal

Set terminal line parameters

##### no

Negate a command or set its defaults

##### monitor

Copy debug output to the current terminal line

---

### 1.3.60 test send-failure-event-report <0-255>

#### Command

```
test send-failure-event-report <0-255>
```

#### Parameters

test

Various testing commands

send-failure-event-report

Send a test OML failure event report to the BSC

<0-255>

BTS Number

### 1.3.61 who

#### Command

```
who
```

#### Parameters

who

Display who is on vty

## 1.4 config

The config node is the root for all configuration commands, which are identical to the config file format. Changes made on the telnet VTY can be made persistent with the 'write file' command.

### 1.4.1 banner motd default

#### Command

```
banner motd default
```

#### Parameters

banner

Set banner string

motd

Strings for motd

default

Default string

## 1.4.2 banner motd file [FILE]

### Command

```
banner motd file [FILE]
```

### Parameters

#### banner

Set banner

#### motd

Banner for motd

#### file

Banner from a file

#### [FILE]

Filename

## 1.4.3 bts BTS\_NR

### Command

```
bts BTS_NR
```

### Global attributes

#### Flag: !

This command applies immediately

### Parameters

#### bts

Select a BTS to configure

#### BTS\_NR

BTS Number

## 1.4.4 cpu-sched

### Command

```
cpu-sched
```

### Parameters

#### cpu-sched

Configure CPU Scheduler related settings

---

### 1.4.5 ctrl

#### Command

```
ctrl
```

#### Parameters

ctrl

Configure the Control Interface

### 1.4.6 e1\_input

#### Command

```
e1_input
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

e1\_input

Configure E1/T1/J1 TDM input

### 1.4.7 enable password (8|) WORD

#### Command

```
enable password (8|) WORD
```

#### Parameters

enable

Modify enable password parameters

password

Assign the privileged level password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN 'enable' password string

---

### 1.4.8 enable password LINE

#### Command

```
enable password LINE
```

#### Parameters

##### enable

Modify enable password parameters

##### password

Assign the privileged level password

##### LINE

The UNENCRYPTED (cleartext) 'enable' password

### 1.4.9 hostname WORD

#### Command

```
hostname WORD
```

#### Parameters

##### hostname

Set system's network name

##### WORD

This system's network name

### 1.4.10 line vty

#### Command

```
line vty
```

#### Parameters

##### line

Configure a terminal line

##### vtty

Virtual terminal

---

### 1.4.11 log alarms <2-32700>

#### Command

```
log alarms <2-32700>
```

#### Parameters

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

<2-32700>

Maximum number of messages to log

### 1.4.12 log file FILENAME [blocking-io]

#### Command

```
log file FILENAME [blocking-io]
```

#### Parameters

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

[blocking-io]

Use blocking, synchronous I/O

### 1.4.13 log gsmtap [HOSTNAME]

#### Command

```
log gsmtap [HOSTNAME]
```

#### Parameters

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

---



### 1.4.14 log stderr [blocking-io]

#### Command

```
log stderr [blocking-io]
```

#### Parameters

log

Configure logging sub-system

stderr

Logging via STDERR of the process

[blocking-io]

Use blocking, synchronous I/O

### 1.4.15 log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)

#### Command

```
log syslog (authpriv|cron|daemon|ftp|lpr|mail|news|user|uucp)
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

authpriv

Security/authorization messages facility

cron

Clock daemon (cron/at) facility

daemon

General system daemon facility

ftp

Ftp daemon facility

lpr

Line printer facility

mail

Mail facility

news

News facility

user

Generic facility

uucp

UUCP facility

### 1.4.16 log syslog local <0-7>

#### Command

```
log syslog local <0-7>
```

#### Parameters

log

Configure logging sub-system

syslog

Logging via syslog

local

Syslog LOCAL facility

<0-7>

Local facility number

### 1.4.17 log systemd-journal [raw]

#### Command

```
log systemd-journal [raw]
```

#### Parameters

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

[raw]

Offload rendering of the meta information (location, category) to systemd

### 1.4.18 no banner motd

#### Command

```
no banner motd
```

#### Parameters

no

Negate a command or set its defaults

banner

Set banner string

motd

Strings for motd

### 1.4.19 no enable password

#### Command

```
no enable password
```

#### Parameters

no

Negate a command or set its defaults

enable

Modify enable password parameters

password

Assign the privileged level password

### 1.4.20 no hostname [HOSTNAME]

#### Command

```
no hostname [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

hostname

Reset system's network name

[HOSTNAME]

Host name of this router

### 1.4.21 no log alarms

#### Command

```
no log alarms
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

alarms

Logging alarms to osmo\_strrb

### 1.4.22 no log file FILENAME

#### Command

```
no log file FILENAME
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

file

Logging to text file

FILENAME

Filename

### 1.4.23 no log gsmtap [HOSTNAME]

#### Command

```
no log gsmtap [HOSTNAME]
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

gsmtap

Logging via GSMTAP

[HOSTNAME]

Host name to send the GSMTAP logging to (UDP port 4729)

### 1.4.24 no log stderr

#### Command

```
no log stderr
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

stderr

Logging via STDERR of the process

### 1.4.25 no log syslog

#### Command

```
no log syslog
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

syslog

Logging via syslog

### 1.4.26 no log systemd-journal

#### Command

```
no log systemd-journal
```

#### Parameters

no

Negate a command or set its defaults

log

Configure logging sub-system

systemd-journal

Logging to systemd-journal

### 1.4.27 no service advanced-vty

#### Command

```
no service advanced-vty
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

---

### 1.4.28 no service terminal-length [<0-512>]

#### Command

```
no service terminal-length [<0-512>]
```

#### Parameters

no

Negate a command or set its defaults

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

[<0-512>]

Number of lines of VTY (0 means no line control)

### 1.4.29 no stats reporter log [NAME]

#### Command

```
no stats reporter log [NAME]
```

#### Parameters

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

log

Report to the logger

[NAME]

Name of the reporter

### 1.4.30 no stats reporter statsd [NAME]

#### Command

```
no stats reporter statsd [NAME]
```

#### Parameters

---

no

Negate a command or set its defaults

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

### 1.4.31 password (8|) WORD

Command

```
password (8|) WORD
```

Parameters

password

Assign the terminal connection password

8

Specifies a HIDDEN password will follow

dummy string

WORD

The HIDDEN line password string

### 1.4.32 password LINE

Command

```
password LINE
```

Parameters

password

Assign the terminal connection password

LINE

The UNENCRYPTED (cleartext) line password

### 1.4.33 phy <0-255>

Command

```
phy <0-255>
```

Global attributes

Flag: !

This command applies immediately

Parameters

phy

Select a PHY to configure

<0-255>

PHY number

### 1.4.34 service advanced-vty

Command

```
service advanced-vty
```

Parameters

service

Set up miscellaneous service

advanced-vty

Enable advanced mode vty interface

### 1.4.35 service terminal-length <0-512>

Command

```
service terminal-length <0-512>
```

Parameters

service

Set up miscellaneous service

terminal-length

System wide terminal length configuration

<0-512>

Number of lines of VTY (0 means no line control)

---



### 1.4.36 show history

#### Command

```
show history
```

#### Parameters

##### show

Show running system information

##### history

Display the session command history

### 1.4.37 stats interval <0-65535>

#### Command

```
stats interval <0-65535>
```

#### Parameters

##### stats

Configure stats sub-system

##### interval

Set the reporting interval

##### <0-65535>

Interval in seconds (0 disables the reporting interval)

### 1.4.38 stats reporter log [NAME]

#### Command

```
stats reporter log [NAME]
```

#### Parameters

##### stats

Configure stats sub-system

##### reporter

Configure a stats reporter

##### log

Report to the logger

##### [NAME]

Name of the reporter

---

### 1.4.39 stats reporter statsd [NAME]

#### Command

```
stats reporter statsd [NAME]
```

#### Parameters

stats

Configure stats sub-system

reporter

Configure a stats reporter

statsd

Report to a STATSD server

[NAME]

Name of the reporter

### 1.4.40 stats-tcp batch-size <1-65535>

#### Command

```
stats-tcp batch-size <1-65535>
```

#### Parameters

stats-tcp

Configure stats sub-system

batch-size

Set the number of tcp sockets that are processed per stats polling interval

<1-65535>

Number of sockets per interval

### 1.4.41 stats-tcp interval <0-65535>

#### Command

```
stats-tcp interval <0-65535>
```

#### Parameters

stats-tcp

Configure stats sub-system

interval

Set the tcp socket stats polling interval

<0-65535>

Interval in seconds (0 disables the polling interval)

---

### 1.4.42 timer [(bts|abis)] [TNNNN] [(<0-2147483647>|default)]

#### Command

```
timer [(bts|abis)] [TNNNN] [(<0-2147483647>|default)]
```

#### Parameters

##### timer

Configure or show timers

##### [bts]

BTS process timers

##### [abis]

Abis (RSL) related timers

##### [TNNNN]

T- or X-timer-number -- 3GPP compliant timer number of the format '1234' or 'T1234' or 't1234'; Osmocom-specific timer number of the format: 'X1234' or 'x1234'.

##### [<0-2147483647>]

New timer value

##### [default]

Set to default timer value

### 1.4.43 vty telnet-port <0-65535>

#### Command

```
vty telnet-port <0-65535>
```

#### Parameters

##### vty

Configure the VTY

##### telnet-port

Set the VTY telnet port

##### <0-65535>

TCP Port number

## 1.5 config-log

The log node is commonly available in all Osmocom programs and allows configuring logging to stderr and/or log files, including logging category and level filtering as well as output formatting options. Note that the 'logging enable' command is required to make logging commands available on the telnet VTY.

### 1.5.1 logging color (0|1)

#### Command

```
logging color (0|1)
```

#### Parameters

##### logging

Configure logging

##### color

Configure color-printing for log messages

0

Don't use color for printing messages

1

Use color for printing messages

### 1.5.2 logging filter all (0|1)

Disable/enable general log output on a given target. Typically, 'logging filter all 1' allows to see the usual log output on a given target. Setting to '0' can be useful when logging to the telnet VTY console: mute all log output to allow typing VTY commands on the telnet prompt without interference from log output; 'logging filter all 1' then re-enables logging in the same log output configuration as before. Some applications provide more specific filters, e.g. to log a given IMSI only. To employ such filters, set 'logging filter all 0' to disable general logging, and then enable a more specific filter instead.

#### Command

```
logging filter all (0|1)
```

#### Parameters

##### logging

Configure logging

##### filter

Filter log messages

all

Do you want to log all messages?

0

Only print messages matched by other filters

1

Bypass filter and print all messages

### 1.5.3 logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglo...

#### Command

```
logging level (rsl|oml|rll|rr|meas|pag|l1c|l1p|dsp|pcu|ho|trx|loop|abis|rtp|lglobal| ↔
llapd|linp|lmux|lmi|lmib|lms|lctrl|lgtp|lstats|lgsup|loap|lss7|lscpp|lsua|lm3ua| ↔
lmgcp|ljibuf|lrspro|lns|lbssgp|lnsdata|lnssignal|liuup|lpfcp|lcsn1) (debug|info| ↔
notice|error|fatal)
```

#### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

##### rsl

A-bis Radio Siganlling Link (RSL)

##### oml

A-bis Network Management / O&M (NM/OML)

##### rll

A-bis Radio Link Layer (RLL)

##### rr

Layer3 Radio Resource (RR)

##### meas

Radio Measurement Processing

##### pag

Paging Subsystem

##### l1c

Layer 1 Control (MPH)

##### l1p

Layer 1 Primitives (PH)

##### dsp

DSP Trace Messages

##### pcu

PCU interface

##### ho

Handover

##### trx

TRX interface

##### loop

Control loops

---

abis  
A-bis Input Subsystem

rtp  
Realtime Transfer Protocol

lglobal  
Library-internal global log family

llapd  
LAPD in libosmogsm

linp  
A-bis Input Subsystem

lmux  
A-bis B-Subchannel TRAU Frame Multiplex

lmi  
A-bis Input Driver for Signalling

lmib  
A-bis Input Driver for B-Channels (voice)

lsms  
Layer3 Short Message Service (SMS)

lctrl  
Control Interface

lgtp  
GPRS GTP library

lstats  
Statistics messages and logging

lgsup  
Generic Subscriber Update Protocol

loap  
Osmocom Authentication Protocol

lss7  
libosmo-sigtran Signalling System 7

lsccp  
libosmo-sigtran SCCP Implementation

lsua  
libosmo-sigtran SCCP User Adaptation

lm3ua  
libosmo-sigtran MTP3 User Adaptation

lmgcp  
libosmo-mgcp Media Gateway Control Protocol

---

ljibuf	libosmo-netif Jitter Buffer
lrspro	Remote SIM protocol
lns	GPRS NS layer
lbssgp	GPRS BSSGP layer
lndata	GPRS NS layer data PDU
lnsignal	GPRS NS layer signal PDU
liuup	Iu UP layer
lpfcp	libosmo-pfcp Packet Forwarding Control Protocol
lcsn1	libosmo-csn1 Concrete Syntax Notation 1 codec
debug	Log debug messages and higher levels
info	Log informational messages and higher levels
notice	Log noticeable messages and higher levels
error	Log error messages and higher levels
fatal	Log only fatal messages

#### 1.5.4 logging level force-all (debug|info|notice|error|fatal)

##### Command

```
logging level force-all (debug|info|notice|error|fatal)
```

##### Parameters

##### logging

Configure logging

##### level

Set the log level for a specified category

**force-all**

Globally force all logging categories to a specific level. This is released by the 'no logging level force-all' command. Note: any 'logging level <category> <level>' commands will have no visible effect after this, until the forced level is released.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages

### 1.5.5 logging level set-all (debug|info|notice|error|fatal)

**Command**

```
logging level set-all (debug|info|notice|error|fatal)
```

**Parameters****logging**

Configure logging

**level**

Set the log level for a specified category

**set-all**

Once-off set all categories to the given log level. There is no single command to take back these changes -- each category is set to the given level, period.

**debug**

Log debug messages and higher levels

**info**

Log informational messages and higher levels

**notice**

Log noticeable messages and higher levels

**error**

Log error messages and higher levels

**fatal**

Log only fatal messages



### 1.5.6 logging print category (0|1)

#### Command

```
logging print category (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem name

### 1.5.7 logging print category-hex (0|1)

#### Command

```
logging print category-hex (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### category-hex

Configure log message

0

Don't prefix each log message

1

Prefix each log message with category/subsystem nr in hex ('<000b>')

### 1.5.8 logging print extended-timestamp (0|1)

#### Command

```
logging print extended-timestamp (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### extended-timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp with YYYYMMDDhhmmssnnn

### 1.5.9 logging print file (0|1|basename) [last]

#### Command

```
logging print file (0|1|basename) [last]
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### file

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the source file and line

##### basename

Prefix each log message with the source file's basename (strip leading paths) and line

##### [last]

Log source file info at the end of a log line. If omitted, log source file info just before the log text.

### 1.5.10 logging print level (0|1)

#### Command

```
logging print level (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### level

Configure log message

0

Don't prefix each log message

1

Prefix each log message with the log level name

### 1.5.11 logging print thread-id (0|1)

#### Command

```
logging print thread-id (0|1)
```

#### Parameters

##### logging

Configure logging

##### print

Log output settings

##### thread-id

Configure log message logging Thread ID

0

Don't prefix each log message

1

Prefix each log message with current Thread ID

## 1.5.12 logging timestamp (0|1)

### Command

```
logging timestamp (0|1)
```

### Parameters

#### logging

Configure logging

#### timestamp

Configure log message timestamping

0

Don't prefix each log message

1

Prefix each log message with current timestamp

## 1.5.13 no logging level force-all

### Command

```
no logging level force-all
```

### Parameters

no

Negate a command or set its defaults

#### logging

Configure logging

#### level

Set the log level for a specified category

#### force-all

Release any globally forced log level set with 'logging level force-all <level>'

## 1.6 config-stats

### 1.6.1 disable

### Command

```
disable
```

### Parameters

disable

Disable the reporter

## 1.6.2 enable

### Command

```
enable
```

### Parameters

enable

Enable the reporter

## 1.6.3 flush-period <0-65535>

### Command

```
flush-period <0-65535>
```

### Parameters

flush-period

Configure stats sub-system

<0-65535>

Send all stats even if they have not changed (i.e. force the flush) every N-th reporting interval. Set to 0 to disable regular flush (default).

## 1.6.4 level (global|peer|subscriber)

### Command

```
level (global|peer|subscriber)
```

### Parameters

level

Set the maximum group level

global

Report global groups only

peer

Report global and network peer related groups

subscriber

Report global, peer, and subscriber groups

---

### 1.6.5 local-ip ADDR

#### Command

```
local-ip ADDR
```

#### Parameters

##### local-ip

Set the IP address to which we bind locally

##### ADDR

IP Address

### 1.6.6 mtu <100-65535>

#### Command

```
mtu <100-65535>
```

#### Parameters

##### mtu

Set the maximum packet size

##### <100-65535>

Size in byte

### 1.6.7 no local-ip

#### Command

```
no local-ip
```

#### Parameters

##### no

Negate a command or set its defaults

##### local-ip

Set the IP address to which we bind locally

### 1.6.8 no mtu

#### Command

```
no mtu
```

#### Parameters

##### no

Negate a command or set its defaults

##### mtu

Set the maximum packet size

---

### 1.6.9 no prefix

#### Command

```
no prefix
```

#### Parameters

no

Negate a command or set its defaults

prefix

Set the item name prefix

### 1.6.10 prefix PREFIX

#### Command

```
prefix PREFIX
```

#### Parameters

prefix

Set the item name prefix

PREFIX

The prefix string

### 1.6.11 remote-ip ADDR

#### Command

```
remote-ip ADDR
```

#### Parameters

remote-ip

Set the remote IP address to which we connect

ADDR

IP Address

### 1.6.12 remote-port <1-65535>

#### Command

```
remote-port <1-65535>
```

#### Parameters

remote-port

Set the remote port to which we connect

<1-65535>

Remote port number

---

## 1.7 config-line

### 1.7.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

##### bind

Accept VTY telnet connections on local interface

##### A.B.C.D

Local interface IP address (default: 127.0.0.1)

##### [<0-65535>]

Local TCP port number

### 1.7.2 login

#### Command

```
login
```

#### Parameters

##### login

Enable password checking

### 1.7.3 no login

#### Command

```
no login
```

#### Parameters

##### no

Negate a command or set its defaults

##### login

Enable password checking



## 1.8 config-e1\_input

### 1.8.1 e1\_line <0-255> connect-timeout <0-60>

#### Command

```
e1_line <0-255> connect-timeout <0-60>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

connect-timeout

Set connect timeout

<0-60>

Connect timeout in seconds (0 to disable)

### 1.8.2 e1\_line <0-255> driver (misdn|misdn\_lapd|dahdi|e1d|ipa|unixsocket)

#### Command

```
e1_line <0-255> driver (misdn|misdn_lapd|dahdi|e1d|ipa|unixsocket)
```

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

driver

Set driver for this line

misdn

mISDN supported E1 Card (kernel LAPD)

misdn\_lapd

mISDN supported E1 Card (userspace LAPD)

dahdi

DAHDI supported E1/T1/J1 Card

e1d

osmo-e1d supported E1 interface

ipa

IPA TCP/IP input

unixsocket

Unix socket input

### 1.8.3 e1\_line <0-255> ipa-keepalive <1-300> <1-300>

Command

```
e1_line <0-255> ipa-keepalive <1-300> <1-300>
```

Global attributes

Flag: !

This command applies immediately

Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

ipa-keepalive

Enable IPA PING/PONG keep-alive

<1-300>

Idle interval in seconds before probes are sent

<1-300>

Time to wait for PONG response

### 1.8.4 e1\_line <0-255> keepalive

Command

```
e1_line <0-255> keepalive
```

Library specific attributes

Flag: I

This command applies on IPA link establishment

Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

keepalive

Enable keep-alive probing

### 1.8.5 e1\_line <0-255> keepalive <1-300> <1-20> <1-300>

#### Command

```
e1_line <0-255> keepalive <1-300> <1-20> <1-300>
```

#### Library specific attributes

#### Flag: I

This command applies on IPA link establishment

#### Parameters

##### e1\_line

Configure E1/T1/J1 Line

##### <0-255>

Line Number

##### keepalive

Enable keep-alive probing

##### <1-300>

Idle interval in seconds before probes are sent

##### <1-20>

Number of probes to sent

##### <1-300>

Delay between probe packets in seconds

### 1.8.6 e1\_line <0-255> name .LINE

#### Command

```
e1_line <0-255> name .LINE
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### e1\_line

Configure E1/T1/J1 Line

##### <0-255>

Line Number

##### name

Set name for this line

##### .LINE

Human readable name

---

### 1.8.7 e1\_line <0-255> pcap .FILE

#### Command

```
e1_line <0-255> pcap .FILE
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

pcap

Setup a pcap recording of E1 traffic for line

.FILE

Filename to save the packets to

### 1.8.8 e1\_line <0-255> port <0-255>

#### Command

```
e1_line <0-255> port <0-255>
```

#### Library specific attributes

Flag: L

This command applies on E1 line update

#### Parameters

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

port

Set physical port/span/card number

<0-255>

E1/T1 Port/Span/Card number

### 1.8.9 e1\_line <0-255> socket .SOCKET

#### Command

```
e1_line <0-255> socket .SOCKET
```

#### Library specific attributes

#### Flag: L

This command applies on E1 line update

#### Parameters

#### e1\_line

Configure E1/T1/J1 Line

#### <0-255>

Line Number

#### socket

Set socket path for unixsocket

#### .SOCKET

socket path

### 1.8.10 ipa bind A.B.C.D

#### Command

```
ipa bind A.B.C.D
```

#### Library specific attributes

#### Flag: L

This command applies on E1 line update

#### Parameters

#### ipa

ipa driver config

#### bind

Set ipa local bind address

#### A.B.C.D

Listen on this IP address (default 0.0.0.0)

---

### 1.8.11 ipa ip-dscp (oml|rsl) <0-63>

#### Command

```
ipa ip-dscp (oml|rsl) <0-63>
```

#### Library specific attributes

#### Flag: I

This command applies on IPA link establishment

#### Parameters

##### ipa

ipa driver config

##### ip-dscp

Set IP DSCP value for outbound packets

##### oml

Set IP DSCP for OML link

##### rsl

Set IP DSCP for RSL link

##### <0-63>

IP DSCP Value to use

### 1.8.12 ipa socket-priority (oml|rsl) <0-255>

#### Command

```
ipa socket-priority (oml|rsl) <0-255>
```

#### Library specific attributes

#### Flag: I

This command applies on IPA link establishment

#### Parameters

##### ipa

ipa driver config

##### socket-priority

Set socket priority value for outbound packets

##### oml

Set socket priority for OML link

##### rsl

Set socket priority for RSL link

##### <0-255>

socket priority value to use (>6 requires CAP\_NET\_ADMIN)

### 1.8.13 no e1\_line <0-255> ipa-keepalive

#### Command

```
no e1_line <0-255> ipa-keepalive
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### no

Negate a command or set its defaults

#### e1\_line

Configure E1/T1/J1 Line

#### <0-255>

Line Number

#### ipa-keepalive

Enable IPA PING/PONG keep-alive

### 1.8.14 no e1\_line <0-255> keepalive

#### Command

```
no e1_line <0-255> keepalive
```

#### Library specific attributes

#### Flag: I

This command applies on IPA link establishment

#### Parameters

#### no

Negate a command or set its defaults

#### e1\_line

Configure E1/T1/J1 Line

#### <0-255>

Line Number

#### keepalive

Enable keep-alive probing

### 1.8.15 no e1\_line <0-255> pcap

#### Command

```
no e1_line <0-255> pcap
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

no

Negate a command or set its defaults

e1\_line

Configure E1/T1/J1 Line

<0-255>

Line Number

pcap

Disable pcap recording of E1 traffic for line

## 1.9 config-ctrl

### 1.9.1 bind A.B.C.D [<0-65535>]

#### Command

```
bind A.B.C.D [<0-65535>]
```

#### Parameters

bind

Set bind address to listen for Control connections

A.B.C.D

Local IP address (default 127.0.0.1)

[<0-65535>]

Local TCP port number



## 1.10 config-cpu-sched

### 1.10.1 cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]

#### Command

```
cpu-affinity (self|all|<0-4294967295>|THREADNAME) CPUHEXMASK [delay]
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### cpu-affinity

Set CPU affinity mask on a (group of) thread(s)

#### self

Set CPU affinity mask on thread running the VTY

#### all

Set CPU affinity mask on all process' threads

#### <0-4294967295>

Set CPU affinity mask on a thread with specified PID

#### THREADNAME

Set CPU affinity mask on a thread with specified thread name

#### CPUHEXMASK

CPU affinity mask

#### [delay]

If set, delay applying the affinity mask now and let the app handle it at a later point

### 1.10.2 policy rr <1-32>

#### Command

```
policy rr <1-32>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### policy

Set the scheduling policy to use for the process

#### rr

Use the SCHED\_RR real-time scheduling algorithm

#### <1-32>

Set the SCHED\_RR real-time priority

## 1.11 phy

### 1.11.1 instance <0-255>

#### Command

```
instance <0-255>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### instance

Select a PHY instance to configure

#### <0-255>

PHY Instance number

### 1.11.2 no instance <0-255>

#### Command

```
no instance <0-255>
```

#### Parameters

#### no

Negate a command or set its defaults

#### instance

Select a PHY instance to remove

#### <0-255>

PHY Instance number

### 1.11.3 virtual-um bts-multicast-group GROUP

#### Command

```
virtual-um bts-multicast-group GROUP
```

#### Parameters

#### virtual-um

Virtual Um layer

#### bts-multicast-group

Configure the BTS multicast group

#### GROUP

(null)

---

### 1.11.4 virtual-um bts-udp-port <0-65535>

#### Command

```
virtual-um bts-udp-port <0-65535>
```

#### Parameters

virtual-um

Virtual Um layer

bts-udp-port

Configure the BTS UDP port

<0-65535>

(null)

### 1.11.5 virtual-um ms-multicast-group GROUP

#### Command

```
virtual-um ms-multicast-group GROUP
```

#### Parameters

virtual-um

Virtual Um layer

ms-multicast-group

Configure the MS multicast group

GROUP

(null)

### 1.11.6 virtual-um ms-udp-port <0-65535>

#### Command

```
virtual-um ms-udp-port <0-65535>
```

#### Parameters

virtual-um

Virtual Um layer

ms-udp-port

Configure the MS UDP port

<0-65535>

(null)

---

### 1.11.7 virtual-um net-device NETDEV

#### Command

```
virtual-um net-device NETDEV
```

#### Parameters

virtual-um

Virtual Um layer

net-device

Configure the network device

NETDEV

(null)

### 1.11.8 virtual-um ttl <0-255>

#### Command

```
virtual-um ttl <0-255>
```

#### Parameters

virtual-um

Virtual Um layer

ttl

Configure the TTL for transmitted multicast GSMTAP packets

<0-255>

(null)

## 1.12 phy-inst

### 1.12.1 osmotrx maxdly <0-63>

Access Burst is the first burst a mobile transmits in order to establish a connection and it is used to estimate Timing Advance (TA) which is then applied to Normal Bursts to compensate for signal delay due to distance. So changing this setting effectively changes maximum range of the cell, because Access Bursts with a delay higher than this value will be ignored.

#### Command

```
osmotrx maxdly <0-63>
```

#### Parameters

### 1.12.2 osmotrx maxdlynb <0-63>

USE FOR TESTING ONLY, DO NOT CHANGE IN PRODUCTION USE! During the normal operation, delay of Normal Bursts is controlled by the Timing Advance loop and thus Normal Bursts arrive to a BTS with no more than a couple GSM symbols, which is already taken into account in osmo-trx. Changing this setting will have no effect in production installations except increasing osmo-trx CPU load. This setting is only useful when testing with a transmitter which cannot precisely synchronize to the BTS downlink signal, like R&S CMD57.

#### Command

```
osmotrx maxdlynb <0-63>
```

#### Parameters

## 1.13 bts

### 1.13.1 agch-queue-mgmt default

#### Command

```
agch-queue-mgmt default
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

agch-queue-mgmt

AGCH queue mgmt

default

Reset clean parameters to default values

### 1.13.2 agch-queue-mgmt threshold <0-100> low <0-100> high <0-100000>

#### Command

```
agch-queue-mgmt threshold <0-100> low <0-100> high <0-100000>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

---

**agch-queue-mgmt**

AGCH queue mgmt

**threshold**

Threshold to start cleanup

&lt;0-100&gt;

in % of the maximum queue length

**low**

Low water mark for cleanup

&lt;0-100&gt;

in % of the maximum queue length

**high**

High water mark for cleanup

&lt;0-100000&gt;

in % of the maximum queue length

**1.13.3 band (450|GSM450|480|GSM480|750|GSM750|810|GSM810|850|GSM850|900|GSM900|1800|DCS...****Command**

```
band (450|GSM450|480|GSM480|750|GSM750|810|GSM810|850|GSM850|900|GSM900|1800|DCS1800 ←  
|1900|PCS1900)
```

**Parameters****band**

Set the frequency band of this BTS

450

Alias for GSM450

GSM450

450Mhz

480

Alias for GSM480

GSM480

480Mhz

750

Alias for GSM750

GSM750

750Mhz

810

Alias for GSM810

GSM810

810Mhz

850

Alias for GSM850

GSM850

850Mhz

900

Alias for GSM900

GSM900

900Mhz

1800

Alias for DCS1800

DCS1800

1800Mhz

1900

Alias for PCS1900

PCS1900

1900Mhz

### 1.13.4 description .TEXT

Command

```
description .TEXT
```

Parameters

description

Save human-readable description of the object

.TEXT

Text until the end of the line

### 1.13.5 gsmtap-remote-host [HOSTNAME]

Command

```
gsmtap-remote-host [HOSTNAME]
```

Parameters

gsmtap-remote-host

Enable GSMTAP Um logging (see also 'gsmtap-sapi')

[HOSTNAME]

Remote IP address or hostname ('localhost' if omitted)

### 1.13.6 gsmtap-sapi (bcch|ccch|rach|agch|pch|sdccch|tch/f|tch/h|pacch|pdtch|ptcch|cbch|sa...

#### Command

```
gsmtap-sapi (bcch|ccch|rach|agch|pch|sdccch|tch/f|tch/h|pacch|pdtch|ptcch|cbch|sa...
```

#### Parameters

gsmtap-sapi

Enable sending of UL/DL messages over GSMTAP

bcch

BCCH

ccch

CCCH

rach

RACH

agch

AGCH

pch

PCH

sdccch

SDCCCH

tch/f

TCH/F

tch/h

TCH/H

pacch

PACCH

pdtch

PDTCH

ptcch

PTCCH

cbch

CBCH

sacch

SACCH



### 1.13.7 gsmtap-sapi (enable-all|disable-all)

#### Command

```
gsmtap-sapi (enable-all|disable-all)
```

#### Parameters

##### gsmtap-sapi

Enable/disable sending of UL/DL messages over GSMTAP

##### enable-all

Enable all kinds of messages (all SAPI)

##### disable-all

Disable all kinds of messages (all SAPI)

### 1.13.8 ipa unit-id <0-65534> <0-255>

#### Command

```
ipa unit-id <0-65534> <0-255>
```

#### Parameters

##### ipa

ip.access RSL commands

##### unit-id

Set the Unit ID of this BTS

##### <0-65534>

Site ID

##### <0-255>

Unit ID

### 1.13.9 max-ber10k-rach <0-10000>

#### Command

```
max-ber10k-rach <0-10000>
```

#### Global attributes

##### Flag: !

This command applies immediately

#### Parameters

##### max-ber10k-rach

Set the maximum BER for valid RACH requests

##### <0-10000>

BER in 1/10000 units (0=no BER; 100=1% BER)

---

### 1.13.10 min-qual-norm <-100-100>

#### Command

```
min-qual-norm <-100-100>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### min-qual-norm

Set the minimum link quality level of Normal Bursts to be accepted

##### <-100-100>

C/I (Carrier-to-Interference) ratio in centiBels (10e-2 B or 10e-1 dB)

### 1.13.11 min-qual-rach <-100-100>

#### Command

```
min-qual-rach <-100-100>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### min-qual-rach

Set the minimum link quality level of Access Bursts to be accepted

##### <-100-100>

C/I (Carrier-to-Interference) ratio in centiBels (10e-2 B or 10e-1 dB)

### 1.13.12 no description

#### Command

```
no description
```

#### Parameters

##### no

Negate a command or set its defaults

##### description

Remove description of the object

---

### 1.13.13 no gsmtap-remote-host

#### Command

```
no gsmtap-remote-host
```

#### Parameters

no

Negate a command or set its defaults

gsmtap-remote-host

Disable GSMTAP Um logging

### 1.13.14 no gsmtap-sapi (bcch|ccch|rach|agch|pch|sdccch|tch/f|tch/h|pacch|pdtch|ptcch|cbch...

#### Command

```
no gsmtap-sapi (bcch|ccch|rach|agch|pch|sdccch|tch/f|tch/h|pacch|pdtch|ptcch|cbch|sacch)
```

#### Parameters

no

Negate a command or set its defaults

gsmtap-sapi

Disable sending of UL/DL messages over GSMTAP

bcch

BCCH

ccch

CCCH

rach

RACH

agch

AGCH

pch

PCH

sdccch

SDCCH

tch/f

TCH/F

tch/h

TCH/H

pacch

PACCH

pdTch

PDTCH

ptcch

PTCCH

cbch

CBCH

sacch

SACCH

### 1.13.15 no oml remote-ip A.B.C.D

Command

```
no oml remote-ip A.B.C.D
```

Parameters

no

Negate a command or set its defaults

oml

OML Parameters

remote-ip

OML IP Address

A.B.C.D

OML IP Address

### 1.13.16 no supp-meas-info toa256

Command

```
no supp-meas-info toa256
```

Global attributes

Flag: !

This command applies immediately

Parameters

no

Negate a command or set its defaults

supp-meas-info

Configure the RSL Supplementary Measurement Info

toa256

Report the TOA in 1/256th symbol periods

---

### 1.13.17 oml remote-ip A.B.C.D

#### Command

```
oml remote-ip A.B.C.D
```

#### Parameters

oml

OML Parameters

remote-ip

OML IP Address

A.B.C.D

OML IP Address

### 1.13.18 paging lifetime <0-60>

#### Command

```
paging lifetime <0-60>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

paging

Paging related parameters

lifetime

Maximum lifetime of a paging record

<0-60>

Maximum lifetime of a paging record (secods)

### 1.13.19 paging queue-size <1-1024>

#### Command

```
paging queue-size <1-1024>
```

#### Global attributes

Flag: !

This command applies immediately

## Parameters

### paging

Paging related parameters

### queue-size

Maximum length of BTS-internal paging queue

<1-1024>

Maximum length of BTS-internal paging queue

## 1.13.20 pcu-socket PATH

### Command

```
pcu-socket PATH
```

## Parameters

### pcu-socket

Configure the PCU socket file/path name

### PATH

UNIX socket path

## 1.13.21 rtp ip-dscp <0-63>

### Command

```
rtp ip-dscp <0-63>
```

## Application specific attributes

### Flag: 1

This command applies for newly created lchans

## Parameters

### rtp

RTP parameters

### ip-dscp

Specify DSCP for RTP/IP packets

<0-63>

The DSCP value (upper 6 bits of TOS)

---

### 1.13.22 rtp jitter-buffer <0-10000> [adaptive]

#### Command

```
rtp jitter-buffer <0-10000> [adaptive]
```

#### Application specific attributes

#### Flag: 1

This command applies for newly created lchans

#### Parameters

##### rtp

RTP parameters

##### jitter-buffer

RTP jitter buffer

##### <0-10000>

Jitter buffer in ms

##### [adaptive]

Enable adaptive RTP jitter buffering

### 1.13.23 rtp port-range <1-65534> <1-65534>

#### Command

```
rtp port-range <1-65534> <1-65534>
```

#### Parameters

##### rtp

RTP parameters

##### port-range

Range of local ports to use for RTP/RTCP traffic

##### <1-65534>

Port range start (inclusive)

##### <1-65534>

Port range end (inclusive)

### 1.13.24 rtp socket-priority <0-255>

#### Command

```
rtp socket-priority <0-255>
```

#### Application specific attributes

#### Flag: 1

This command applies for newly created lchans

#### Parameters

##### rtp

RTP parameters

##### socket-priority

Specify socket priority for RTP/IP packets

##### <0-255>

The socket priority value (> 6 requires CAP\_NET\_ADMIN)

### 1.13.25 smscb queue-hysteresis <0-30>

#### Command

```
smscb queue-hysteresis <0-30>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

##### smscb

SMSCB (SMS Cell Broadcast) / CBCH configuration

##### queue-hysteresis

Hysteresis of the SMSCB (CBCH) queue

##### <0-30>

In count of messages/pages (default: 2)

---



### 1.13.26 smscb queue-max-length <1-60>

#### Command

```
smscb queue-max-length <1-60>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

smscb

SMSCB (SMS Cell Broadcast) / CBCH configuration

queue-max-length

Maximum length of the SMSCB (CBCH) queue

<1-60>

Length in count of messages/pages (default: 15)

### 1.13.27 smscb queue-target-length <1-30>

#### Command

```
smscb queue-target-length <1-30>
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

smscb

SMSCB (SMS Cell Broadcast) / CBCH configuration

queue-target-length

Target length of the SMSCB (CBCH) queue

<1-30>

Length in count of messages/pages (default: 2)

### 1.13.28 **supp-meas-info toa256**

#### Command

```
supp-meas-info toa256
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### supp-meas-info

Configure the RSL Supplementary Measurement Info

#### toa256

Report the TOA in 1/256th symbol periods

### 1.13.29 **trx <0-254>**

#### Command

```
trx <0-254>
```

#### Global attributes

#### Flag: !

This command applies immediately

#### Parameters

#### trx

Select a TRX to configure

#### <0-254>

TRX number

## 1.14 **trx**

### 1.14.1 **ms-power-control (dsp|osmo)**

#### Command

```
ms-power-control (dsp|osmo)
```

#### Parameters

#### ms-power-control

Mobile Station Power Level Control

#### dsp

Handled by DSP

#### osmo

Handled by OsmoBTS

---

### 1.14.2 phy <0-255> instance <0-255>

#### Command

```
phy <0-255> instance <0-255>
```

#### Parameters

##### phy

Configure PHY Link+Instance for this TRX

##### <0-255>

PHY Link number

##### instance

PHY instance

##### <0-255>

PHY Instance number

### 1.14.3 power-ramp max-initial <-10000-100000> (dBm|mdBm)

#### Command

```
power-ramp max-initial <-10000-100000> (dBm|mdBm)
```

#### Parameters

##### power-ramp

Power-Ramp settings

##### max-initial

Maximum initial power

##### <-10000-100000>

Value

##### dBm

Unit is dB (decibels)

##### mdBm

Unit is mdB (milli-decibels, or rather 1/10000 bel)

### 1.14.4 power-ramp step-interval <1-100>

#### Command

```
power-ramp step-interval <1-100>
```

#### Parameters

---

**power-ramp**

Power-Ramp settings

**step-interval**

Power increase by step

&lt;1-100&gt;

Step time in seconds

**1.14.5 power-ramp step-size <1-100000> (dB|mdB)**

## Command

```
power-ramp step-size <1-100000> (dB|mdB)
```

## Parameters

**power-ramp**

Power-Ramp settings

**step-size**

Power increase by step

&lt;1-100000&gt;

Step size

**dB**

Unit is dB (decibels)

**mdB**

Unit is mdB (milli-decibels, or rather 1/10000 bel)

**1.14.6 ta-control interval <0-31>**

## Command

```
ta-control interval <0-31>
```

## Parameters

**ta-control**

Timing Advance Control Parameters

**interval**

Set TA control loop interval

&lt;0-31&gt;

As in P\_CON\_INTERVAL, in units of 2 SACCH periods (0.96 seconds) (default=0, every SACCH block)

### 1.14.7 user-gain <-100000-100000> (dB|mdB)

#### Command

```
user-gain <-100000-100000> (dB|mdB)
```

#### Global attributes

Flag: !

This command applies immediately

#### Parameters

user-gain

Inform BTS about additional, user-provided gain or attenuation at TRX output

<-100000-100000>

Value of user-provided external gain(+)/attenuation(-)

dB

Unit is dB (decibels)

mdB

Unit is mdB (milli-decibels, or rather 1/10000 bel)